Hardware Reference Manual GFK-3047C September 2021

RXi2-UP

Industrial PC (IPC)





Document-History

Rev	Date	Description
	2019-05-	Initial version
А	2019-11-	Emerson rebranding
В	2021-03	Update to IEC/UL 62368
С	2021-09	UKCA Update

Warnings and Caution Notes as Used in this Publication

WARNING

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

ACAUTION

Caution notices are used where equipment might be damaged if care is not taken.

ATTENTION

Indicates a procedure or condition that should be strictly followed to improve these applications.

Note: Notes merely call attention to information that is especially significant to understanding and operating the equipment.

These instructions do not purport to cover all details or variations in equipment, nor to provide for every possible contingency to be met during installation, operation, and maintenance. The information is supplied for informational purposes only, and Emerson makes no warranty as to the accuracy of the information included herein. Changes, modifications, and/or improvements to equipment and specifications are made periodically and these changes may or may not be reflected herein. It is understood that Emerson may make changes, modifications, or improvements to the equipment referenced herein or to the document itself at any time. This document is intended for trained personnel familiar with the Emerson products referenced herein.

Emerson may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not provide any license whatsoever to any of these patents.

Emerson provides the following document and the information included therein as-is and without warranty of any kind, expressed or implied, including but not limited to any implied statutory warranty of merchantability or fitness for particular purpose.

© 2021 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. All other marks are the property of their respective owners.

Preface

Legal Information

Legal Disclaimers

© 2021 Emerson Automation Solutions, Inc. All rights reserved.

The information in this manual is proprietary to and is the confidential information of Emerson Automation Solutions, Inc. and may not be reproduced in whole or in part, for any purpose, in any form or by any means, electronic, mechanical, recording, or otherwise, without written consent of Emerson Automation Solutions, Inc. Use, disclosure, and reproduction is permitted only under the terms of a Emerson Automation Solutions license agreement or explicit written permission of Emerson Automation Solutions. You are not authorized to use this document or its contents until you have read and agreed to the applicable license agreement. Receipt of this publication is considered acceptance of these conditions.

All information contained in this document has been carefully checked and is believed to be entirely reliable and consistent with the product that it describes. However, no responsibility is assumed for inaccuracies. Emerson Automation Solutions assumes no liability due to the application or use of any product or circuit described herein; no liability is accepted concerning the use of Emerson Automation Solutions products in life support systems. Emerson Automation Solutions reserves the right to make changes to any product and product documentation in an effort to improve performance, reliability, or design.

THIS DOCUMENT AND ITS CONTENTS ARE PROVIDED AS IS, WITH NO WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF DESIGN, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM ANY COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

Changes or modifications to this unit, not expressly approved by Emerson Automation Solutions, could void the user's authority to operate the equipment.

All computer code and software contained in this document is licensed to be used only in connection with a Emerson Automation Solutions hardware product. Even if this code or software is merged with any other code or software program, it remains subject to the terms and conditions of this license. If you copy, or merge, this code or software, you must reproduce and include all Emerson Automation Solutions copyright notices and any other proprietary rights notices.

The content of this manual if furnished for informational use only and is subject to change without notice. Reverse engineering of any Emerson Automation Solutions product is strictly prohibited.

In no event will Emerson Automation Solutions be liable for any lost revenue or profits or other special, indirect, incidental and consequential damage, even if Emerson Automation Solutions has been advised of the possibility of such damages, as a result of the usage of this document describes. The entire liability of Emerson Automation Solutions shall be limited to the amount paid by you for this document and its contents.

Emerson Automation Solutions shall have no liability with respect to the infringement of copyrights, trade secrets, or any patents by this document of any part thereof. Please see the applicable software license agreement for full disclaimer or warranties and limitations of liability.

This disclaimer of warranty extends to Emerson Automation Solutions' licensees, to licensees transfers, and to licensees customers or users and is in lieu of all warranties expressed, implied, or statutory, included implied warranties of scalability or fitness for a particular purpose.

The Emerson logo is a trademark of Emerson, Inc. Other brand names and product names contained herein may be claimed as the property of others.

Emerson Automation Solutions, Inc., 2500 Austin Drive, Charlottesville, VA 22911, U.S.A.

Regulatory compliance

Products sold or transferred between companies or operated on company premises (factory floor, laboratory) do not need CE, FCC or equivalent certification. Boards or subsystems which cannot provide a useful function on their own do not need certification.

Certification can only be granted to complete and operational systems. There are authorized testing agencies, regulatory organizations and laboratories who will issue certificates of compliance after system testing.

Emerson Automation Solutions designs and tests all their products for EMI/EMC conformance. Where Emerson Automation Solutions supplies a complete/functional system for use by end users a certificate will be cited in the manuals/documents which are provided with the products. Products manufactured by Emerson Automation Solutions should normally be suitable for use in properly designed and produced customer equipment (system boxes or operational systems) without any major redesign or additional filtering. However, the systems might not conform to specific regulations once assembled and used. The system integrator or installer must test for compliance as required in his country or by the intended application and certify this to the end user.


ESD/EMI issues

ESD (Electro-Static Discharge) and EMI (Electro-Magnetic Interference) issues may show up in complete and operational systems. There are many ways to avoid problems with these issues. Any operational system with cables for I/O signals, connectivity or peripheral devices provides an entry point for ESD and EMI. If Emerson Automation Solutions does not manufacture the complete system, including enclosure and cables, it is the responsibility of the system integrator and end user to protect their system against potential problems. Filtering, optical isolation, ESD gaskets and other measures might be required at the physical point of entry (enclosure wall of box or rack). For example it is state-of-the-art that protection cannot be done at the internal connector of an RTM if a cable is attached and routed outside the enclosure. It has to be done at the physical entry point as specified above.

Products manufactured by Emerson Automation Solutions should normally be suitable for use in properly designed and produced customer equipment (system boxes or operational systems) without any major redesign. However, the systems might be subject to problems and issues once assembled, cabled and used. The end user, system integrator or installer must test for possible problems and in some cases show compliance to local regulations as required in his country or by the intended application.

Waste Disposal

The mark or symbol on any electrical or electronic product shows that this product may not be disposed off in a trash bin. Such goods have to be returned to the original vendor or to a properly authorized collection point.





The black bar underneath the waste bin symbol shows that the product was placed on the market after 13 August 2005. Alternatively the date of 'placed on the market' is shown in place of the bar symbol.

CE conformance declaration

CE certification is required in EU countries for equipment which is used or operated by the end user. Products sold or transferred between companies or operated on company premises (factory floor, laboratory) do not need CE certification.

CE certification can only be granted to complete and operational systems. Boards or subsystems which cannot provide a useful function on their own do not need CE certification.

Emerson Automation Solutions designs and tests all their products for EMI/EMC conformance. Products manufactured by Emerson Automation Solutions should normally be suitable for use in properly designed and produced customer equipment (system boxes or operational systems) without any major redesign or additional filtering. The system integrator or installer must, in any case, test for CE compliance and certify this to the end user.

Where Emerson Automation Solutions supplies a complete/functional system for use by end users in EU countries a CE certificate will be cited in the manuals/documents which are provided with the products. The CE (and year of certification) symbol is shown on the equipment, typically on the type or S/N label or close to the power cable entry.

Emerson Automation Solutions have tested their boards using their own card cages (chassis). Test results of these tests are available upon request.

Corporate addresses

Corporate headquarters

ICC Intelligent Platforms, Inc. 2500 Austin Drive Charlottesville, VA 22911 U.S.A. Phone: +1-800-322-3616 Web: https://www.emerson.com/

Germany	US
ICC Intelligent Platforms GmbH	ICC Intelligent Platforms, Inc.
Memminger Str. 14	2500 Austin Drive
86159 Augsburg	Charlottesville, VA 22911
Germany	U.S.A.
Phone: +49-821-5034-0	Phone: +1-800-322-3616
Fax: +49-821-5034-119	

ICC Intelligent Platforms on the Web:

https://www.emerson.com/

For contact and other information (service, warranty, support etc.) see address list in chapter: <u>'Welcome'</u>.

Welcome

Typographic Conventions

This manual uses the following notation conventions:

- Italics (sometimes additionally in blue color) emphasize words in text or documentation or chapter titles or web addresses if underlined.
- Hexadecimal values (base 16) are represented as digits followed by 'h', for example:
 0Ch.
- Hexadecimal values (base 16) are represented as digits preceded by 'H', for example: HOC.
- Hexadecimal values (base 16) are represented as digits preceded by '\$', for example:
 \$0C.
- Binary values (base 2) are represented as digits followed by 'b', for example 01b
- The use of a '#' (hash) suffix to a signal name indicates an active low signal. The signal is either true when it is at logic zero level (voltage close to 0 V) or the signal initiates actions on a high-to-low transition.
- The use of a '\' (backslash) prefix to a signal name indicates an active low signal. The signal is either true when it is at logic zero level (voltage close to 0 V) or the signal initiates actions on a high-to-low transition.
- Text in Courier font indicates a command entry or output from a ICC Intelligent Platforms embedded PC product using the built-in character set.
- Notes, warning symbols and cautions call attention to essential information.

Product Properties

Altitude

Altitude, air pressure and ambient temperature influence the thermal operation of the components described in this manual. They have been developed and tested at about 500 m (1650 ft.) above sea level at a typical ambient temperature of 20 °C (68 °F). Because of only marginal variations within a limited range of altitudes these products operate as specified within altitudes from sea level to 2000 m (~6560 ft). This is with reference to temperature ranges of air-cooled versions. ICC Intelligent Platforms can assist the user of these components in planning operation outside this altitude range upon request.

Options

This manual describes the basic product plus all options. Your product may not have all options implemented. Please verify with your purchase contract which options are implemented. Descriptions of options which are not implemented obviously do not apply to your product.

Support, Service and Warranty

The manufacturer grants the original purchaser of ICC Intelligent Platforms products a warranty of 24 months from the date of delivery. For details regarding this warranty refer to Terms & Conditions of the initial sale.

For support on the web and product information, visit our website at

https://www.emerson.com/

Contact Information

If you purchased this product through an Authorized Channel Partner, contact the seller directly.

General Contact Information

Online technical support and GlobalCare	https://www.emerson.com/Industrial-
	Automation-Controls/support
Additional information	https://www.emerson.com

Technical Support

Contact us by telephone, email, or at <u>https://www.emerson.com/Industrial-Automation-</u> Controls/support

Americas		
Phone	1-888-565-4155	
If toll free option is unavailable	1-434-214-8532	
Tech Support Email	support.mas@emerson.com	
Sales/Order Support Email	customercare.mas@emerson.com	
Primary language of support	English	

Americas

Europe (not Germany), Middle-East, & Africa

Phone	+800-4-444-8001
If toll free option is unavailable	+420-225-379-328
Tech Support Email	support.mas.emea@emerson.com
Sales/Order Support Email	customercare.emea.mas@emerson.com
Primary language of support	English, German, Italian, Spanish

Germany

	-
Address	ICC Intelligent Platforms GmbH
	Memminger Str. 14
	86159 Augsburg, Germany
Phone	+49-821–5034–170
Fax	+49-821–5034–119
Tech Support Email	mas.support.augsburg@emerson.com
Primary language of support	English, German

Asia Pacific

Phone	+86-400-842-8599
India, Indonesia & Pakistan	+65-6955-9413
Tech Support Email	support.mas.apac@emerson.com
Sales/Order Support Email	customercare.cn.mas@emerson.com
Primary language of support	Chinese, Japanese, English

Contents

Section 1: Ov	erview
---------------	--------

	1.1	Capability and Compatibility	3
	1.2	Software Requirements	4
	1.3	Features	4
Section 2:		Unpacking and Inspection	
	2.1	Package Contents	6
	2.2	Available Options and Accessories	6
	2.3	ESD and EMI	7
	2.4	Jnpack and Inspect	8
	2.5	Handling	9
Sectio	on 3:	Mounting	
	3.1	Flat Wall Mounting	10
		8.1.1 Flat Wall Mounting with Mounting Plates	11
		B.1.2 Flat Wall Mounting Through Wall	12
	3.2	Slim Mounting	13
		3.2.1 Slim Mounting with Mounting Plate	13
Sectio	on 4:	Installation and Startup	
	4.1	General Installation Guidelines	14
	4.2	Required Materials	14
		1.2.1 Power Supply	14
		1.2.2 Keyboard	15
		1.2.3 Video Monitor	15
	4.3	Minimum System Requirements	15
	4.4	Power-On Self-Test (POST)	15
	4.5	nstallation Procedures	15
		1.5.1 PCIe Board Installation	15
		1.5.2 Mini PCle Add-on Board Installation	20
		1.5.3 SIM Card Interface Installation	22
		1.5.4 M.2 A-Key Add-on Board Installation	24
		1.5.5 M.2 M-Key Add-on Board Installation	26
	4.6	nitial Startup	27
	4.7	JEFI Firmware Setup	27
	4.8	RTC Battery Replacement	28

Section 5:	HardwareInterface	
5.1	Interface	32
	5.1.1 Status LEDs	32
	5.1.2 Power Button	33
	5.1.3 TPM Button	33
	5.1.4 Ethernet Ports (Eth1, Eth2, Eth3, Eth4, Eth5)	34
	5.1.5 Ethernet LEDs	34
	5.1.6 Display Port	35
	5.1.7 USB 3.0 Connectors	36
	5.1.8 Power Connectors	37
	5.1.9 Internal SATA Connector	38
	5.1.10 CFast Connector	38
	5.1.11 Serial (COM) Ports	38
	5.1.12 SATA 2.5 inch Drive Tray Replacement	40
5.2	Additional Devices	44
	5.2.1 Temperature Sensor	44
	5.2.2 NVSRAM	45
Section 6:	Hardware and Firmware Programmable Devices	
6.1	SMBUS Devices	46
6.2	Ethernet	46
6.3	PCIe Ports	46
6.4	PCI Routing	47
Section 7:	Specifications	
7.1	Power Consumption	50
7.2	EnvironmentalSpecifications	51
	7.2.1 Ambient Temperatures and Humidity	51
	7.2.2 Shock and Vibration without 2.5 inch Mass Storage	51
	7.2.3 Shock and Vibration with 2.5 inch Mass Storage	51
	7.2.4 Altitude	51
	7.2.5 Regulations and Certification	52
	7.2.6 Battery	53
7.3	Technical Specifications	54
Section 8:	Related Documents	
Section 9:	Appendix: Open Source Software (OSS) List (V0.x)	

Section 10: Acronyms and Abbreviations

Section 11: Glossary

List of Tables

Table 2-1	Delivery Volume6
Table 2-2	Available Options6
Table 2-3	Available Accessories6
Table 5-1	Status LEDs
Table 5-2	Ethernet Interface
Table 5-3	ETH1 to ETH4 LEDs
Table 5-4	ETH5 LEDs
Table 5-5	Display Port Interface Signals
Table 5-6	USB Port 1-2 Signals
Table 5-7	USB Port 3-4 Signals
Table 5-8	Power Connectors
Table 5-9	Serial Ports
Table 5-10	THRM LED Indication
Table 6-1	SMBus Devices46
Table 6-2	PC Bus Device
Table 6-3	PCI Express Port Usage47
Table 6-4	PCI Routing
Table 7-1	Input Power
Table 7-2	Power Entry50
Table 7-3	Temperature Specifications51
Table 7-4	Shock and Vibration Specifications without Additional 2.5 inch Mass Storage51
Table 7-5	Maximum Altitude
Table 7-6	Regulations and Certification
Table 7-7	Technical Specifications
Table 8-1	Related Documents
Table 9-1	Open Source Software (OSS) List56

List of Figures

Figure 1-1	0-slot RXi2-UP IPC	1
Figure 1-2	1-slot RXi2-UP IPC	2
Figure 1-3	2-slot RAID RXi2-UP IPC	2
Figure 1-4	4-slot RXi2-UP IPC	3
Figure 1-5	4-slot RAID RXi2-UP IPC	3
Figure 1-6	2-slot RXi2-UP IPC System Block Diagram	5
Figure 2-1	RXi2-UP IPC Packaging	9
Figure 3-1	Heat Dissipation Clearance	11
Figure 3-2	Flat Wall Mounting with Mounting Plates	12
Figure 3-3	Flat Wall Mounting Through Wall	12
Figure 3-4	Conceptual drawing of Slim Mounting with Mounting Plate	13
Figure 4-1	RXi2-UP Top Cover	16
Figure 4-2	PCIe Support Bracket Screws	16
Figure 4-3	Removed PCIe Support Bracket and Screws	17
Figure 4-4	Removed PCIe Slot Bracket	17
Figure 4-5	PCIe Board Bracket Inserted into Slot	18
Figure 4-6	PCIe Board Bracket Inserted into PCIe Connector	18
Figure 4-7	Reattached PCIe Support Bracket	19
Figure 4-8	Reattached PCIe Bracket Screws	19
Figure 4-9	Card Holder Adjustment	20
Figure 4-10	Reattached Top Cover	20
Figure 4-11	Short Position for mPCIe Bracket	21
Figure 4-12	Long Position for mPCIe Bracket	21
Figure 4-13	Mini PCle Board Inserted	22
Figure 4-14	Mini PCle Board Mounted to RXi2-UP IPC	22
Figure 4-15	SIM Interface Connected to mPCIe – Unlocked but Closed	23
Figure 4-16	SIM Card Holder Open	23
Figure 4-17	SIM Card Inserted	24
Figure 4-18	SIM Card Holder Closed and Locked	24
Figure 4-19	RXi2-UP IPC Connector Slot	25
Figure 4-20		
ligule 4-20	M.2 A-Key Insertion into Connector Slot	25
Figure 4-20	M.2 A-Key Insertion into Connector Slot M.2 A-Key Mounted to RXi2-UP IPC	
-		26
Figure 4-21	M.2 A-Key Mounted to RXi2-UP IPC	26 26
Figure 4-21 Figure 4-22	M.2 A-Key Mounted to RXi2-UP IPC M RXi2-UP IPC Connector Slot	26 26 27

Figure 5-1	RXi2-UP IPC Hardware Interface Overview			
Figure 5-2	RXi2-UP IPC Hardware Interface Overview (2-slot Option)32			
Figure 5-3	Status LEDs			
Figure 5-4	Power Button			
Figure 5-5	Ethernet Interface Ports (1–slot Option)			
Figure 5-6	RXi2-UP IPC GBE			
Figure 5-7	Display Port Interface Ports (2–slot Option)35			
Figure 5-8	USB 3.0 Connectors			
Figure 5-9	Power Connectors			
Figure 5-10	CFast Connector			
Figure 5-11	Serial Ports – 2-Slot Variant			
Figure 5-12	Serial Ports – 4-Slot Variant			
Figure 5-13	Pin Assignment			
Figure 5-14	2.5 inch SATA Drive Device Tray Location40			
Figure 5-15	Removing Storage Device Tray from Mounted Position41			
Figure 5-16	Storage Device Tray Fully Open Position41			
Figure 5-17	Removal of Storage Device Tray42			
Figure 5-18	Storage Device Tray Screws42			
Figure 5-19	Storage Device Tray43			
Figure 5-20	Tray insertion43			
Figure 5-21	Inserted tray44			
Figure 7-1	RXi2-UP Data Nameplate52			
Figure 7-2	RXi2-UP Data Nameplate for version with preinstalled graphic card			
(R2UCN1DCC2T0AW03)53				

Overview

A Computer-On-Module (COM) is a module containing all components necessary for a bootable host computer, packaged as a super component. A COM requires a carrier board to connect I/O and power up. COMs are used to build modular solutions and offer Original Equipment Manufacturers (OEMs) fast time-to-market with reduced development cost. Like integrated circuits, they provide OEMs with significant freedom in meeting form-fit-function requirements. For these reasons, the COM methodology has gained much popularity with OEMs in the embedded industry.

The RXi2-UP IPC industrial computing platform delivers compact, rugged, mid to high performance computing and high performance graphics capabilities to run Human-machine Interface (HMI), historian, and analytics applications for real-time control of operations. It offers the expansion of 0, 1, 2, or 4 (mini and low profile) PCI Express (PCIe) slots and CFast storage.

The RXi2-UP IPC (NextGenIPC) is composed of the following components:

- bCOM6L20 COM Express module based on Intel[®] Kaby Lake 7th Generation Core[™] i3/5/7 and Xeon[®] V6 series
- CEC09 COM Express carrier board
- PERC12 (1-slot), PERC10 (2-slot) and PERC11 (4-slot) PCIe riser board
- PIP24VDC power supply module
- SRC SATA riser board for additional 2.5 inch mass storage devices support
- Industrial grade enclosure with heat sink for the module and carrier components

This chapter describes the features, capabilities, and compatibilities of the RXi2-UP IPC and its components.





Figure 1-3 2-slot RAID RXi2-UP IPC





Figure 1-5 4-slot RAID RXi2-UP IPC



1.1 Capability and Compatibility

The bCOM6L20 COM Express module is a fully IBM-AT compatible single board computer module containing many functions in a very small form-factor. It is based on the PICMG COM Express Module Base Specification V2.1 Type 6. (Refer to the documentation located at <u>www.picmg.org</u>.) The bCOM6L20 uses the Intel x86 7th Generation Core Processor and Intel Xeon v6 Processors to provide most of the interface.

The CEC09 COM Express carrier board is also compliant with the PICMG COM Express Module Base Specification V2.1 Type 6.

The PERC10 and PERC11 PCI Express (PCIe) riser boards provide signals from the Edge connector interface to a PCIe packet switch device (limited to PCIe Gen2) through PCIe expansion slots. The PERC12 riser board provides signals from the Edge and is a passive device that supports a PCIe Gen3 link.

The PIP24VDC power supply module provides a voltage input of nominal 24 V (± 25%).

1.2 Software Requirements

- Microsoft[®] Windows[®] 10 Professional 64-Bit
- Linux[®] Kernel 4.8

1.3 Features

RXi2-UP IPC module features are as follows:

- 7th Generation Intel Core Processor and Intel Xeon Processor E3-1200 v6 product line
 - i3-7100E 35W 2c/4t HD530 2.9GHz 3MB, 8GB no ECC with QM175
 - i3-7102E 25W 2c/4t HD530 2.1GHz 3MB, 8GB no ECC with QM175
 - i3-7100E 35W 2c/4t HD530 2.9GHz 3MB, 8GB ECC with CM238
 - i3-7102E 25W 2c/4t HD530 2.1GHz 3MB, 8GB ECC with CM238
 - i5-7440EQ 45/35W 4c/4t HD530 2.9 (max3.6) GHz 6MB 16GB no ECC with QM175
 - i5-7442EQ 25W 4c/4t HD530 2.1 (max2.9) GHz 6MB, 16GB no ECC with QM175
 - i7-7820EQ 45/35W 4c/8t HD530 3.0 (max3.7) GHz 8MB, 16GB no ECC with QM175
 - E3-1505L v6 25W 4c/8t HDP530 2.2 (max3.0) GHz 8MB, 32GB ECC with CM238
 - E3-1505M v6 45/35W 4c/8t HDP530 3.0 (max4.0) GHz 8MB,32GB ECC with CM238
- System memory:
 - 8 GB up to 32 GB DDR3 SDRAM (soldered) with ECC running at 2133/2400 MHz
 - Organized dual channel with two ranks each
- 2x Display Port
- 4x USB 3.0
- 5x Gig Ethernet ports (1 from module plus 4 Ethernet controller (4x i210IT) with TimeSYNC IEEE1588 and 802.1AS
 - Alternative 1x GigE and 4x SFP (4x i210IS) (contact Emerson for support)
- Mini PCIe slot (half and full size)
 - Unified Infrastructure Management (UIM) interface
- M.2 PCIe M-Key (PCIe Gen3 x4) and SATA capability
- M.2 PCIe A-Key (general connectivity)
- TPM V1.2 or V2.0
- Up to 4 serial interfaces (2x RS-232, 2x galvanic isolated RS-485/RS-422)
- Capability for two additional 2.5 inch storage devices with SATA riser board/RAID option
- UIM interface
- 0, 1, 2 or 4-slot with active/passive riser board (depending on slot size)

• Operating at 24 V dc (±25%), including over and under-voltage protection




Figure 1-6 2–slot RXi2-UP IPC System Block Diagram

Unpacking and Inspection

If the RXi2-UP IPC operates by an enhanced ambient temperature up to 65°C (149°F), the surface of the enclosure, especially the heat sink, can reach a temperature of 85°C (185°F) and above. Be careful and do not touch the RXi2-UP IPC with bare fingers.

Si le RXi2-UP IPC est opérée à une température ambiante élevée jusqu'à 70 ° C (149 ° F), la surface du boîtier, en particulier le dissipateur thermique, peut atteindre une température de 85 ° C (185 ° F) et plus. Soyez prudent et ne touchez pas le RXi2-UP IPC avec les doigts nus.

Install the RXi2-UP IPC only in rooms with restricted access.

This chapter describes unpacking, initial inspection, and required preparation considerations prior to using the RXi2-UP IPC. Perform the procedures in this chapter to verify proper operation after shipping and prior to system integration.

2.1 Package Contents

Verify that the delivered package contains the contents listed in the following table.

Table 2-1 Delivery Volume

Qty	Item	Purpose	
1	RXi2-UP	RXi2-UP Industrial PC	

2.2 Available Options and Accessories

The following tables list the available options and accessories for the RXi2-UP IPC.

Table 2-2 Available Options

Item	Description
R2U0N1E1A1T0A	0-slot, i5-7442EQ (35W), 8 GB DDR4 no-ECC, Win10, 128 GB M.2 SSD
R2U1N1B0A1T0A	1-slot, i3-7102E (25W) 8 GB DDR4 (no-ECC) , no OS, 128 GB M.2 SSD
R2U1N1C0A1T0A	1-slot, E3-1505L (25W) 32 GB DDR4 w/ ECC, no OS, 128 GB M.2 SSD
R2U2N1D0A2T0A	2-slot, E3-1505M (45W) 32 GB DDR4 w/ ECC, no OS, 128 GB M.2 SSD
R2U2N1C0B2T0F	2-slot E3-1505L (25W), 32 GB DDR4 w/ ECC, no OS 256 GB M.2 SSD
R2U4N1F0A2T0A	4-slot, i7-7820EQ (45W) 16 GB DDR4 (no-ECC) , no OS, 128 GB M.2 SSD

Table 2-3 Available Accessories

Item	Description
Contact Emerson for details	10 pcs Flat mounting kit
R2X00ACCMP05	1 pc Flat mounting kit
Contact Emerson for details	1 pc Slim mounting kit

Note: For the most current information on options and accessories, contact the nearest Emerson sales or service office, or an authorized Emerson sales representative. Options are subject to change without notice.

2.3 ESD and EMI

Electrostatic Discharge (ESD) is the discharge of static electricity. Electromagnetic Interference (EMI) is a disturbance generated by an external source that affects an electrical circuit by electromagnetic induction, electrostatic coupling, or conduction. ESD and EMI issues may show up in complete and operational systems. There are many ways to avoid problems with these issues.

Any operational system with cables for I/O signals, connectivity or peripheral devices provides an entry point for ESD and EMI. If Emerson does not manufacture the complete system, including enclosure and cables, it is the responsibility of the system integrator and end user to protect their system against potential problems. Filtering, optical isolation, ESD gaskets and other measures might be required at the physical point of entry (enclosure wall of box or rack). For example it is state-of-the-art that protection cannot be done at the internal connector of an RTM if a cable is attached and routed outside the enclosure. It has to be done at the physical entry point as specified in this document.

Products manufactured by Emerson should normally be suitable for use in properly designed and produced customer equipment (system boxes or operational systems) without any major redesign. However, the systems might be subject to problems and issues once assembled, cabled and used. The end user, system integrator or installer must test for possible problems and in some cases show compliance to local regulations as required in his country or by the intended application.

ESD is a major cause of electronic component failure. The component has been packed in a static-safe bag to protect it from ESD while it is in the bag. Before removing the component or any other electronic product from its static-safe bag, be prepared to handle it in a static-safe environment.

ACAUTION

Static-sensitive Devices: Handle only at static-safe work stations.

A CAUTION

This is an FCC Class A product for use in an industrial environment. In a home or residential environment, this product may cause radio interference in which case the user may be required to take adequate measures.

ACAUTION

Drain static electricity before you install or remove any parts. Installing or removing modules without observing this precaution could result in damage to this and/or other modules or component in your system.

Wear a properly-functioning anti-static strap and make sure you are fully grounded. Any surface upon which you place the unprotected module or unit should be static-safe, which is usually facilitated by the use of anti-static mats. From the time it is removed from the anti-static bag until it is in the board carrier and functioning properly, extreme care should be taken to avoid zapping the component with ESD. Be aware that you could zap the component without knowing it; a small discharge, imperceptible to the eye and touch, can often be enough to damage electronic components. Extra caution should be taken in cold and dry weather when electrostatics easily builds up.

Only after ensuring that both you and the surrounding area are protected from ESD, carefully remove the component from the shipping carton by grasping the module on its edges. Place the component, in its anti-static bag, flat down on a suitable surface. You may then remove the component from the anti-static bag by tearing the ESD warning labels.

2.4 Unpack and Inspect

WARNING

Before installing or removing any board or module, ensure that the system power and external supplies have been turned off.

A WARNING

Do not apply power to the board if it has visible damage. Doing so may cause further, possibly irreparable damage, as well as introduce a fire or shock hazard.

ATTENTION

Retain all packing material in case of future need.

Before unpacking the board or module, or fitting the device into your system, read the manual carefully. Also adhere to the following guidelines:

- Observe all precautions for electrostatic sensitive modules.
- If the product contains batteries, do not place it on conductive surfaces, anti-static plastic, or a sponge, which can cause shocks and lead to battery or board trace damage.
- Do not exceed the <u>specified</u> operational temperatures. Batteries and storage devices might also have temperature restrictions.
- Keep all original packaging material for future storage or warranty shipments of the board.

After unpacking the component, inspect it for visible damage that may have occurred during shipping or unpacking. Although the product is carefully packaged to protect it against the rigors of shipping, it is still possible that shipping damages may occur. Careful inspection of the shipping carton should reveal some information about how the package was handled by the shipping service.

If evidence of damage or rough handling is found (usually in the form of bent component leads or loose socketed components), notify the shipping service as soon as possible and contact Emerson for additional instructions. Depending on the severity of the damage, it may be necessary to return the product to the factory for repair.



2.5 Handling

A WARNING

If the RXi2-UP IPC operates with an enhanced ambient temperature up to 65°C (149°F), the surface of the enclosure, especially the heat sink, can reach a temperature of 85°C (185°F) and above. Be careful and do not touch the RXi2-UP IPC with bare fingers.

A CAUTION

Install the RXi2-UP IPC only in rooms with restricted access.

A CAUTION

Hot surfaces are possible, depending on factors such as CPU load, ambient temperature, and so forth. Be careful and do not touch the RXi2-UP with bare fingers!

Mounting

RXi2-UP IPC cooling is designed for wall mounted orientation of the box. There are two possible mounting options:


- Flat wall mounting
- Slim mounting (contact Emerson for instructions)

3.1 Flat Wall Mounting

There are two types of wall mounting:

- Flat wall mounting with mounting plates
- Flat wall mounting through the wall

For the best results of heat dissipation, observe the minimum clearances for flat wall mounting as illustrated in the following figure.






3.1.1 Flat Wall Mounting with Mounting Plates

The screws selected for use depends on the nature of the wall. The mounting plates have four drills holes with a diameter of 5.3 mm (0.209 in), so the maximum screw diameter cannot be higher than 5.2 mm (0.205 in). The head of the screws must be smaller than 10 mm (0.4 in) to pass the hole of the top fixing points of the mounting plate.

Note: The mounting plate for the 2-slot and 4-slot version will be the same.



3.1.2 Flat Wall Mounting Through Wall

To mount the IPC with screws from the wall side, place drill holes in the wall. Refer to the following figure for the positions for the holes. The thread in the enclosure is a M6 with a usable thread length of 15 mm (0.60 in). Select the screw length so so that a minimum of 10 mm (0.4 in) thread will be used and torque to 3.5 Nm (30.98 in lb).





Figure 3-3 Flat Wall Mounting Through Wall

3.2 Slim Mounting

3.2.1 Slim Mounting with Mounting Plate

For details please contact Emerson IP support.

Figure 3-4 Conceptual drawing of Slim Mounting with Mounting Plate



Installation and Startup

This chapter describes the installation and initial startup operations. Because the unit is available in several options, the description in this chapter is related to the standard configuration.

WARNING

Before installing or removing any component, make sure that the system power and external supplies have been turned off.

A CAUTION

Static-sensitive Devices: Handle only at static-safe work stations.

Drain static electricity before you install or remove any parts. Installing or removing modules without observing this precaution could result in damage to this and/or other components in your system.

4.1 General Installation Guidelines

Adhere to the following guidelines during installation:

- Observe all safety procedures to avoid damaging the system and protect operators and users.
- Before installing or removing any board, verify that the system power and external supplies have been turned off.
- Verify that the jumpers (if any) are correctly configured for your application.
- Make sure the RXi2-UP IPC is properly mounted.
- Connect all I/O cables.
- Do not restore power until all components are fitted correctly into the system and all connections have been made properly.

4.2 Required Materials

The following items are required to start the RXi2-UP IPC in a standard configuration:

- Power supply
- Keyboard and mouse
- Video monitor

4.2.1 Power Supply

WARNING

Verify that the power supply is turned OFF while installing boards or modules into the

RXi2-UP IPC.

- Verify that the power supply is capable of meeting the total power requirements of the RXi2-UP IPC. (Refer to the section Specifications.)
- Verify you do not have the power supply turned ON while opening the enclosure to install add-on boards and modules into the RXi2-UP IPC (such as the PCIe boards or internal SATA drives).

4.2.2 Keyboard

A compatible USB keyboard for initial system operation of the RXi2-UP IPC is required. Depending on your application, this may be a standard keyboard, or one that uses membrane switches for harsh environments.

4.2.3 Video Monitor

Any video monitor with native Display Port (or a suitable adaptor for the Display Port) can be used for initial setup.

4.3 Minimum System Requirements

The RXi2-UP IPC has been thoroughly tested and is nearly ready for usage in the target system. To verify operation for the first time, Emerson recommends that you only configure a minimal system. It is not necessary to have disk drives, a Flash disk, or other accessories connected to perform the Power-On Self-Test (POST).

4.4 Power-On Self-Test (POST)

Each time the computer boots up it must pass the POST. If the computer does not pass any of the test items, the unit will fail the POST.

Test items are as follows:

- CPU must exit the reset status mode and thereafter be able to execute instructions
- SPI Flash ROM and Non-Volatile Random-Access Memory (NOVRAM) is readable
- Checksum is valid (readable)
- CMOS is readable (CMOS checksum is valid)
- CPU is able to read all forms of memory, such as the memory controller, memory bus, and memory module
- First 64 KB of memory is operational and has the capability to be Read and Written to and from, and contains the POST code
- I/O bus/controller is accessible
- I/O bus is able to Read/Write from the video subsystem and be able to read all video RAM

4.5 Installation Procedures

4.5.1 PCIe Board Installation

Install a PCIe board into the RXi2-UP IPC using the following procedure.

To install the PCIe board


WARNING

Verify that the power supply is turned OFF while installing boards or modules into the RXi2-UP IPC.

1. Remove the top cover by removing the four screws in each corner (Tx20).



2. Remove the PCIe support bracket screws (qty 4) (Tx10).



3. Remove the PCIe support bracket.



4. Remove the PCIe slot bracket.



5. Insert the PCIe board bracket into the slot.



Figure 4-5 PCIe Board Bracket Inserted into Slot

6. Insert the PCIe board bracket into the PCIe connector at the riser board. Ensure that the board fits properly into the connector and is well connected.



Figure 4-6 PCIe Board Bracket Inserted into PCIe Connector

7. Reattach the PCIe support bracket.



Figure 4-7 Reattached PCIe Support Bracket

8. Reattach the four PCIe support bracket screws (Tx10 [0.6 Nm/5.3 in lb]).



Figure 4-8 Reattached PCIe Bracket Screws

9. Adjust the card holder.



10. Reattach the top cover by reattaching the four screws in each corner (Tx20 [1 Nm/8.9 in lb]).



Mini PCIe Add-on Board Installation 4.5.2

ATTENTION

The information described in this section applies to service technicians only.

The Mini PCIe (mPCIe) board is connected to the RXi2-UP IPC by inserting the board into either a full size slot or a half size slot, depending on the size of the Mini PCIe board you are inserting.

To install the Mini PCIe board

A WARNING

Verify that the power supply is turned OFF while installing boards or modules into the RXi2-UP IPC.

Adjust the slot size to allow for the size of the Mini PCIe board being inserted (Tx8 [0.6 Nm/5.3 in lb]).




Figure 4-12 Long Position for mPCle Bracket



2. Insert the Mini PCIe board into the connector slot.





3. Mount Mini PCIe board into the connector slot using standard screws (Tx8 [0.6 Nm/5.3 in lb]) screw: ISO14583 M2.5 x 6 or M2.5 x 5.



4.5.3 SIM Card Interface Installation

To install the SIM card

WARNING

Verify that the power supply is turned OFF while installing boards or modules into the RXi2-UP IPC.

1. Open SIM card holder by moving the upper part in the OPEN \rightarrow direction (as shown on the part).



2. Open the SIM card holder.





3. Insert the SIM card.

Figure 4-17 SIM Card Inserted



Lock the SIM card into position by moving the upper part in the LOCK ← direction (as shown on the part).



Figure 4-18 SIM Card Holder Closed and Locked

4.5.4 M.2 A-Key Add-on Board Installation

ATTENTION

The information described in this section applies to service technicians only.

The M.2 board is connected to the RXi2-UP IPC by inserting the board with a form factor of 2230.

To install the M.2 A-key board

WARNING

Verify that the power supply is turned OFF while installing boards or modules into the RXi2-UP IPC.

1. Insert the M.2 A-Key board into the connector slot.

Figure 4-19 RXi2-UP IPC Connector Slot



Figure 4-20 M.2 A-Key Insertion into Connector Slot



2. Mount the M.2 A-Key board into the connector slot using standard screws (Tx8 [0.45 Nm/5 in lb]), screw: ISO14583 M2.5 x 6, or M2.5 x 5.





4.5.5 M.2 M-Key Add-on Board Installation

ATTENTION

The information described in this section applies to service technicians only.

The M.2 board is connected to the RXi2-UP IPC by inserting the board with a with form factor of 2242, 2260, 2280 or 22110.

To install the M.2 M-key board

WARNING

Verify that the power supply is turned OFF while installing boards or modules into the RXi2-UP IPC.

1. Insert the M.2 M-Key board into the connector slot.



Figure 4-22 M RXi2-UP IPC Connector Slot



Figure 4-23 M.2 M-Key Insertion into Connector Slot

2. Mount the M.2 M-Key board into the connector slot using standard screws (Tx8 [0.45 Nm/5 in lb]) screw: ISO14583 M2.5 x 6 or M2.5 x 5.



Figure 4-24 M.2 M-Key Mounted to RXi2-UP IPC

4.6 Initial Startup

A few seconds after powering up, the RXi2-UP IPC system BIOS banner displays on the screen. If you do not see any error messages up to this point, the RXi2-UP IPC is running properly and ready to be configured for your application.

4.7 UEFI Firmware Setup

To enter setup during the initial startup sequence: press the [Delete] or [F2] during the startup sequence.

Adhere to the applicable on-screen messages when prompted.

Note: If the RXi2-UP IPC does not perform as described, some damage may have occurred during shipment or the board is not installed or configured properly. Contact Emerson for technical support. (Refer to the section Contact Information.)

4.8 RTC Battery Replacement

WARNING

There is danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type to Murata CR2032W. Dispose used batteries according to Emerson provided instructions and applicable local regulations.

A CAUTION

Static-sensitive Devices: Handle only at static-safe work stations.

ATTENTION

The information described in this section applies to service technicians only.

To replace the Real Time Clock (RTC) battery

- 1. Remove power from the RXi2-UP IPC.
- 2. Loosen the four captive screws on the RXi2-UP IPC's top cover and remove it.

Figure 4-25 RTC B

RTC Battery (Removed Top Cover)



- 3. Remove the RTC battery from the retaining clip.
- 4. Install a new RTC battery in the retaining clip with the positive (+) side up.

WARNING

Do not use a different battery type other than the same type as removed or equivalent type to Murata CR2032W as this may present a risk of fire or explosion!

A WARNING

The battery may explode if mistreated. Do not recharge, disassemble, heat above 100° C (212 °F), or incinerate!

5. Reattach the top cover on the IPC and tighten the four screws to secure it.

Hardware Interface

This chapter describes the hardware interface used in the RXi2-UP IPC. The following diagram provides an overview of the way the hardware interface is used.




Figure 5-1 RXi2-UP IPC Hardware Interface Overview

5.1 Interface




Figure 5-2 RXi2-UP IPC Hardware Interface Overview (2-slot Option)

5.1.1 Status LEDs

The RXi2-UP IPC contains a set of status LEDs to indicate various functions. The CEC09 provides LEDs on the front panel, in a location near the power connector and power button.

LED Name	Color	LED Status Indication
	Red	Standby power available, but no power good signal active (error condition)
PWR (Power)	Yellow	Standby power valid (S3, S4, S5)
	Green	All power available and valid (SO)
SATA	Green	SATA access in progress (SATA, CFAST, M.2)
THRM	Green	Thermal OK
(Port Expander:	Yellow	T _{Hot} reached (available also in S5 after Shutdown)
P0: Green; P1: Red)	Red	Tcrit reached (available also in S5 after Shutdown)
USER (GPO0)	Green	Switchable from User
TPM		Flashes when TPM button is pressed for a defined amount
(Port Expander:	Yellow	of time
P2: Green and Red)		



5.1.2 Power Button

The Power button powers on the RXi2-UP IPC. It is located on the front panel.



Note: Use an appropriate tool for operation as needed.

Pressing (short push) the power button triggers the operating system to shut down (Power State S5). If the operating system does not immediately shut down, press and hold the Power button for more than 5 seconds to force the RXi2-UP IPC to shut down immediately without support from the operating system.

State S5 (Soft-off mode) switches off the CPU core power and resets the RXi2-UP IPC. The State S5 is indicated with an Amber Power LED. At this state, it is possible to reactivate the RXi2-UP IPC by pressing (short push) the Power button. This action switches on the CPU core voltage and the boards restart.

5.1.3 TPM Button

Pressing the Trusted Platform Module (TPM) button for a defined amount of time activates TPM maintenance mode.

Note: The TPM button is not currently supported. This feature will be implemented later. After implementation, support will depend on the selected configuration.

5.1.4 Ethernet Ports (Eth1, Eth2, Eth3, Eth4, Eth5)

Five Ethernet interface ports are available on the RXi2-UP IPC. They are located on the front panel. Ethernet interface requires the use of a CAT 5 cable for proper operation with 100/1000BaseT.



Figure 5-5 Ethernet Interface Ports (1–slot Option)

Table 5-2 Ethernet Interface

10/100BaseT Name	1000BaseT Name	Pin
TxD+	LP_DA+	1
TxD-	LP_DA-	2
RxD+	LP_DB+	3
NC	LP_DC+	4
NC	LP_DC-	5
RxD-	LP_DB-	6
NC	LP_DD+	7
NC	LP_DD-	8

5.1.5 Ethernet LEDs

Two LEDs (green and yellow) are integrated in each of the RJ–45 connector. These LEDs indicate Ethernet interface link status and activity.

Table 5-3 ETH1 to ETH4 LEDs


Pin	LED Color	LED Status Indication
#GBEx_LINK	Green	Solid = 1000 Mbit
		Off = 10/100 Mbit
#GBEx_ACT	Yellow	Solid = No activity, but 10/100/1000 Mbit link
		Blinking = Activity ongoing

Table 5-4 ETH5 LEDs

Pin	LED on RJ–45 Jack	LED Status Indication
#GBE5_LINK	Velleur	Solid = Any LINK
#GBE5_ACT	Yellow	Blinking = ACTIVITY
#GBE5_LINK100	Orange	LINK100
#GBE5_LINK1000	Green	LINK1000

Figure 5-6

RXi2-UP IPC GBE



5.1.6 Display Port

A Display port (DP1 and DP2) interface provides signals for connecting either a suitable monitor or an adaptor to several other display standards.



Figure 5-7 Display Port Interface Ports (2–slot Option)

Table 5-5Display Port Interface Signals	
Signal Name	Pin
TxD0+/-	1/3
TxD1+/-	4/6
TxD2+/-	7/9
TxD3+/-	10/12
AUXSEL	13
NC	14
CLK/AUX+	15
DAT/AUX-	17
HTPLG	18
DP_VCC	
DP_VCC is fused with 2 A fuse, but for normal operation do not exceed 1 A at this pin.	20
GND	2, 5, 8, 11, 16, 19

Table 5-5Display Port Interface Signals

5.1.7 USB 3.0 Connectors

Four USB channels are available at standard USB Type A connectors. Each pair of them is fused with 2 A, but for normal operation do not exceed 0.9 A per connector.

Figure 5-8 USB 3.0 Connectors



Table 5-6 USB Port 1-2 Signals

Signal Name	Pin
FUSE_VCC FUSE_VCC is fused with 2 A fuse, but for normal operation do not exceed 0.9 A current per connector.	1
USB-	2
USB+	3
GND	4
SSRX-	5
SSRX+	6
GND	7
SSTX-	8

Signal Name	Pin
SSTX+	9

Table 5-7USB Port 3-4 Signals

Signal Name	Pin
FUSE_VCC FUSE_VCC is fused with 2 A fuse, but for normal operation do not exceed 0.9 A current per connector.	1
USB-	2
USB+	3
GND	4
SSRX-	5
SSRX+	6
GND	7
SSTX-	8
SSTX+	9

5.1.8 Power Connectors

The power inlet into the RXi2-UP IPC is a Phoenix contact Base strip - MSTB 2.5/ 3-GF - 1776702 connector. The corresponding plug is a type FKCN 2.5/ 3-STF - 1732975 from a Phoenix contact.



Table 5-8

Power Connectors

Signal Name	Pin (Left to Right)
Frame GND	1
Power -	2
Power +	3

The power input is filtered internally on the RXi2-UP IPC. Directly after the power connector Frame GND and Power – are hard connected. When using a power supply with a supply reference to PE ground, connect the +24 V to power plus and the GND to power minus.

ATTENTION

Never use a power supply generating a -24 V output if the positive supply is related to PE ground. It will be shortened if any external device is connected to the RXi2-UP IPC.

ATTENTION


The power input is secured with one 10 A blow fuse. If the input power exceeds the limits, the fuse will be blown to protect all circuitry within the RXi2-UP IPC. Contact Emerson for a suitable replacement.

5.1.9 Internal SATA Connector

One M.2 M-Key (PCIe 4x and SATA) with sizes 2242, 2260, 2280 and 22110 is located inside the RXi2-UP IPC.

5.1.10 CFast Connector

Located on the front of the RXi2-UP IPC is a CFast Type 1 flash connector. CFast is a variant of a CompactFlash that supports a higher maximum transfer rate than current Compact Flash cards. Standard CFast cards can be used for storage of data or the operating system. The device is connected to a standard SATA port of the COM Express module, and is hot plug capable with standard OS.



5.1.11 Serial (COM) Ports

The 0-slot and 1-slot variant of the RXi2-UP IPC is provided with two serial ports. The two serial ports are RS–232 on 9–pin, D-connectors for local terminals or peripheral communication.

The 2-slot and 4-slot variant is equipped with four serial ports. Serial ports 1 and 2 are RS-232, serial ports 3 and 4 are RS-422 / RS-485.

Figure 5-11 Serial Ports – 2-Slot Variant



Serial Ports – 4-Slot Variant Figure 5-12




Table 5-9 Serial Ports

Signal Name	Pin
RS–232 Pin	
DCD	1
RxD	2
TxD	3
DTR	4
GND	5
DSR	6
RTS	7
СТЅ	8
RI	9
RS–422 / RS–485 Pin	
Rx+	1
Rx-	2
Tx-	3
Tx+	4
GND	5

Figure 5-13



12345

6789

For RS-422 and RS-485-4 wire modes, connect the corresponding RX+/- with the TX+/- of the counterpart and vice versa. For RS-485-2 wire mode connect RX+ and TX+ together with the + line of the cable and the RX- and the TX- together with the – line of the cable.

The difference of the various RS–4xx modes is the Tx/Rx control. RS-422 has Tx and Rx always active. RS-485 four-wire enables Tx only when there is something to transmit, Rx is always active. RS-485 two-wire enables Tx and disables Rx when transmitting, disables Tx and enables Rx when not transmitting. The various modes can be selected within the device driver of the used operating system.

5.1.12 SATA 2.5 inch Drive Tray Replacement

ATTENTION

The information described in this section applies to service technicians only.

Two additional 2.5 inch storage devices are available for use with the SATA riser board or the RAID option. The 2.5 inch hard disk trays (located in the front of the unit) can be used as SSD or rotating devices.

ATTENTION

Before before physically ejecting the device, make sure you dismount or eject the drive from the OS.

To replace the 2.5 inch SATA drive

- **Note:** Due to the SAT hot-plug capability, there is no need to power down the unit for replacement. Just make sure you dismount or eject the drive from the OS before physically removing the device.
 - 1. Locate the position of the hard disk device you want to remove.





2. Insert your finger under the handle and carefully remove the storage device tray from the mounted position.



Figure 5-15 Removing Storage Device Tray from Mounted Position

3. Pull down until the device tray is as fully open as possible.



4. Remove the hard disk tray completely from the unit.



5. Unscrew the four mounting screws and separate the hard drive from the tray.



6. Insert the replacement hard drive and screw in the four mounting screws to mount it.






7. Insert the storage device tray ~25.4 mm (1 in) (maximum) into the slot, move it to the right side until the nose is between the guidance mark of the tray, then push it carefully into the slot.



Figure 5-20 Tray insertion 8. Insert the tray until it is fully and firmly seated.



Note: You can lock each SSD tray using the provided key.

5.2 Additional Devices

5.2.1 Temperature Sensor

There are two thermal zones on the CEC09 Carrier board that can be observed with an EMC2113 device. This device contains internal temperature sensors and can connect three external temperature sensors. All external sensors are grouped as one thermal group and placed so that the hottest point can be observed no matter the mounting style.

The EMC2113 device measures the temperature of several higher rated devices (I210IT/IS; RS– 232 Transceiver; 4x PCIe2UART) with the help of a common heatsink

A dual THRM LED located on the front panel indicates the current thermal. For more information, refer to the section <u>Status</u>

Table 5-10 THRM LED Indication

LED Color	LED Status Indication
Green	Everything OK
Yellow	T _{Hot} reached (wired to U3080/SMBus Port Expander via pin 0)
Red	T _{Crit} reached (wired to U3080/SMBus Port Expander via pin 1)

5.2.2 NVSRAM

The RXi2-UP IPC offers Non-Volatile Random Access Memory (NVSRAM) as a mPCIe board addon option that is automatically backed up when the RXi2-UP IPC is switched off or loses power. It is not supplied with battery power but an exhausted Lithium coin battery will not result in a loss of data. Contact Emerson for assistance with option.

Hardware and Firmware Programmable Devices

This chapter describes the hardware and firmware programmable devices of the CEC09 carrier board and the bCOM6L20 module.

6.1 SMBUS Devices

Table 6-1 SMBus Devices

Device	Address	Function
Clock Buffer 8x	1101 110xb [DCh]	PCIe clock
Clock Buffer 4x	1101 110xb [DCh]	PCie clock
PCA9548A	1110 001xb [E2h]	SMBus switch (to avoid address conflicts from add-in boards)
Fan Controller	0101 110xb [5Ch]	Fan controller includes thermal sensors
Port Expander	0100 000xb [40h]	SMBus port expander

Table 6-2 PC Bus Device

Device	Address	Function
24C512	1010 000x [A0h]	Factory EEPROM of bCOM6L20
24C64	1010 111x [AEh]	Factory EEPROM of CEC09

6.2 Ethernet

The Ethernet controllers provide internal EEPROMs, which contain the MAC address, as well as their configuration.

6.3 PCIe Ports

The PCIe ports are provided by the COMe module. The PCIe allocation is provided in the following table.

Table 6-3 PCI Express Port Usage

Source Device	Port	Connected to
COMe PEG	0:3	Riser board
COMe PEG	8:11	M.2 mass storage device
COMe PCle	0	Ethernet #1
COMe PCle	1	Ethernet #2
COMe PCle	2	Ethernet #3
COMe PCle	3	Ethernet #4
COMe PCle	4	М.2 А-Кеу
COMe PCle	5	UART
COMe PCle	6	mPCle

6.4 PCI Routing

The PCI routings in a RXi2-UP IPC are defined in the following table.

Table 6-4PCI Routing

Function	Connected to	Vendor	Device (GPU Dependent)	Bus/Dev/Func	
bCOM6L20	bCOM6L20				
Intel Skylake Host Bridge	_	8086	_	0/00/0	
HD Graphics	_	8086	_	0/2/0	
Gaussian mixture model	_	8086	_	0/8/0	
Intel USB 3.0 XHCI	_	8086	_	0/14/0	
Intel Thermal Subsystem	_	8086	_	0/14/2	
Serial I/O I2C #0	_	8086	_	0/15/0	
Serial I/O I2C #1	-	8086	_	0/152	
Intel CSME HECI	-	8086		0/16/0	
Intel SATA Controller [AHCI]	_	8086	_	0/17/0	
PCI Bridge	I210 #1	8086	_	0/1C/0	
PCI Bridge	1210 #2	8086	—	0/1C/1	
PCI Bridge	I210 #3	8086	_	0/1C/2	
PCI Bridge	1210 #4	8086	_	0/1C/3	
PCI Bridge	M.2 A-Key Slot	8086	_	0/1C/4	
PCI Bridge	Pericom UART	8086	—	0/1C/5	
PCI Bridge	mPCIe Slot	8086	—	0/1C/6	
Intel LPC Controller		8086	_	0/1F/0	
Intel PMC		8086	—	0/1F/2	
Intel HD Audio		8086	_	0/1F/3	
Intel SMBUS		8086	_	0/1F/4	
I219-LM	_	8086	_	0/1F/6	
CEC09					
Riser slot	_	_	_	1/0/0	
Ethernet #1	Front	8086	1531	5/0/0	
Ethernet #2	Front	8086	1531	6/0/0	
Ethernet #3	Front	8086	1531	7/0/0	
Ethernet #4	Front	8086	1531	8/0/0	
M.2 A-Key slot	-		_	A/0/0	
PCIe Serial	Serial	12D8	7954	B/0/0	
Mini PCIe slot	_	-	-	C/0/0	
PERC10 Riser Board					
PCIe to PCIe bridge	PCI Slots	12D8	2312	1/0/0	

PCIe Slot #1	_	_	_	3/0/0
PCIe Slot #2	_	_	_	4/0/0
PERC11 Riser Board				
PCIe to PCIe bridge	PCI Slots	12D8	2612	1/0/0
PCIe Slot #1	_	_	_	2/0/0
PCIe Slot #2	_	_	_	3/0/0
PCIe Slot #3	_	_	_	4/0/0
PCIe Slot #4	_	_	_	5/0/0

Specifications

This chapter provides specifications and useful information for the RXi2-UP IPC.

7.1 Power Consumption

WARNING

The RXI2-UP industrial PC power supply must meet the requirements for SELV (safety extra-low voltage)/LPS (limited power source) or ES1/PS2.

L'alimentation du PC industriel RXI2-UP doit répondre aux exigences SELV (sécurité très basse tension) / LPS (source d'alimentation limitée) ou ES1 / PS2.

Table 7-1Input Power RXi2-UP

Nominal Input	Input Range	Max Input Ripple
24 V	18-30 V (+/-25%)	± 0.2 V

Table 7-2Input Power RXi2-UP with preinstalled graphic card (R2UCN1DCC2T0AW03).

Nominal Input	Input Range	Max Input Ripple
24 V	18.5-30 V (+25%/-23%)	± 0.2 V

Note: Due to high currents in this variant Emerson derates lower tolerance to ensure proper operation.

The current consumption can vary, depending on the CPU, load, and input voltage, as follows:

- $18 \text{ V dc} \rightarrow 4.41 \text{ A}$ (in BurnIn at 25°C (77 °F)
- 24 V dc \rightarrow 3.33 A (in BurnIn at 25°C (77 °F)
- 30 V dc \rightarrow 2.64 A (in BurnIn at 25°C (77 °F)

Table 7-3 Power Entry

Operation	Ambient Temperature	Power ⁺	
		i3 Dual Core, 2.7 GHz,	XEON E3 1505 MV, 2.8
		8 GB RAM, 128 GB SSD	GHz,
			32 GB RAM, 128 GB SSD
UEFI Setup or shell	25°C (77 °F)	13 W	22 W
Windows 10 idle	25°C (77 °F)	9.6 W	10.1 W
Windows 7 Heavy Load Tool	25°C (77 °F)	26 W	60 W
Windows 7 Heavy Load Tool	60°C (140 °F)	27 W	63 W
⁺ Measured at shown ambient temperature. All values are typical.			

Note: The consumption values include the USB keyboard and a SSD hard disk. For each linked Ethernet channel, add 0.5 W.

Power Budget for Add-on Devices

The CEC09 Carrier board supports a power budget for USB devices, SATA devices, and add-on boards up to a total of 25 W. For add-on boards on the riser board, any share between +12 V, 5 V, and 3.3 V power consumption is possible up to 20 W maximum for all two/four boards together.

7.2 Environmental Specifications

7.2.1 Ambient Temperatures and Humidity

Ambient temperatures and humidity values for the RXi2-UP IPC are provided in the following table.

Item	Level A
Temperature	
Storage	-40 to 85°C (-40 to 185 °F)
Operating	-40 to 60°C (-40 to 140 °F)
Humidity	
Operating	
Storage	5 to 95% rH, non-condensing, at 40°C (104 °F)

Table 7-4 Temperature Specifications

7.2.2 Shock and Vibration without 2.5 inch Mass Storage

The RXi2-UP IPC without 2.5 inch mass storage options is designed to meet the shock and vibration values listed in the following table.

Table 7-5Shock and Vibration Specifications without Additional 2.5 inch Mass Storage

Item	Vita 47 V1
Vibration	
Spectrum	5 to 100 Hz
Acceleration	2 g RMS
Shock	
Half sine or sawtooth	20 g
Duration	11 ms

7.2.3 Shock and Vibration with 2.5 inch Mass Storage

Due to additional interchangeable non-rugged mechanical parts, Emerson does not recommend exposing the system to shock and vibration.

7.2.4 Altitude

Altitude, air pressure, and ambient temperature influence the thermal operation of the components described in this document. They have been developed and tested at ~500 m (1650

ft) above sea level at a typical ambient temperature of 20°C (68 °F). Because of only marginal variations within a limited range of altitudes, this product operates as specified within altitudes from sea level to 1,000 m (6,560 ft), depending on the level. This is with reference to temperature ranges of air-cooled versions.

Note: Emerson can assist the user in planning operation outside this altitude range upon request.

Maximum altitude for the RXi2–UP IPC is specified in the following table.

Table 7-6 Maximum Altitude

Item	Level A
Maximum Altitude	
Operating	2 km (6,600 ft)
Storage	12 km (40,000 ft)


7.2.5 Regulations and Certification

Table 7-7 Regulations and Certification

Item	Specification
EMC	EMC Directive 2014/30/EU EN 61000-6-4 Emission standard for industrial environments EN 61000-6-2 Immunity standard for industrial environments FCC Part 15 B This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
	CAN ICES-3 (A)/NMB-3(A)
Product Safety	LVD Directive 2014/35/EU IEC 62368-1 2 nd Edition
	UL 62368-1 (UL file number E214940)
UKCA	Emerson Process Management Shared Service Ltd Meridan East, Meridan Business Park, Leicester LE19 1UX United Kingdom

Figure 7-1 RXi2-UP Data Nameplate

ICC Intelligent Platforms	D-00100 Augoburg
^{SN:} 12345678 Input: 24V 3.5A	DC: A1824 Made in Germany





7.2.6 Battery

The RXi2-UP IPC contains a BR2032 lithium coin battery. The maximum current used by the bCOM6L20 module is 6uA. Depending on the operating hours and temperature, the estimated battery life is 2 to 10 years. Battery current is not used when the RXi2-UP IPC is supplied with 24 V.

7.3 Technical Specifications

Table 7-8Technical Specifications

Item	Specification	
	Intel 7th Generation Core Processors (i3 / i5 / i7)	
Processor	Intel XEON V6 Processors	
Marran	Up to 32 GB DDR4 at 2400 Mhz	
Memory	Soldered, with 32 GB ECC RAM	
NVSRAM	512 KB, 1 MB or 2 MB NVSRAM	
	Storage for process relevant data	
SATA interface	M.2 M-Key SATA (form factor 2242, 2260, 2280, 22110) or optional internal 2.5 inch SATA hard disk drive (HDD)	
Ethernet	5 Ethernet (10, 100, 1000 Mbit) ports	
Wireless Communication	WLAN optional via internal Mini PCIe board site	
Video/graphics interface	2x Display Port	
	4x USB 2.0 Standard ports – External	
USB Interface	2x USB 2.0 Standard ports – Internal	
Serial Communications	RXi2-UP 0/1/2–slot: RS-232 or opto-coupled 422/485	
Serial Communications	RXi2-UP 4–slot: RS-232 and opto-coupled 422/485	
Expansion	Internal Mini PCIe board slot, half and full length (for WLAN, LTE) Internal M.2 A-Key slot, form factor 2230 (WLAN)	
	0 (Slim version) 1, 2 or 4 full size PCIe Expansion slots	
BIOS	UEFI AMI Aptio® 5	
	0-slot: 252 x 203 x 108.5 mm (9.92 x 8 x 4.24 in)	
D imension	1-slot: 252 x 203 x 135.5 mm (9.92 x 8 x 5.33 in)	
Dimensions	2-slot: 252 x 203 x 155.5 mm (9.92 x 8 x 6.13 in)	
	4-slot: 252 x 203 x 195.5 mm (9.92 x 8 x 7.70 in)	
	0-slot: 3.9 Kg (8.60 lb)	
	1-slot: 4.2 kg (9.26lbs)	
Weight	2-slot: 4.4 kg (9.70 lb)	
	4-slot: 4.7 Kg (10.34 lb)	
Enclosure	ure Aluminum and stainless steel	

Related Documents

Table 8-1 Related Documents

Document #	Title
GFK-3015	IPC2018 Industrial PC (IPC) Secure Deployment Guide
GFA-2180	RXi2-UP Industrial PC (IPC) Data Sheet

Appendix: Open Source Software (OSS) List (V0.x)

In accordance with certain software license terms, the Emerson Automation Solutions (Emerson) provides the following software package installations. This code is provided on an asis basis, and Emerson makes no representations or warranties for the use of this code independent of any Emerson provided software or services. Refer to the licenses and copyright notices files for each package for specific license terms that apply to each software bundle associated with this product release. For further details contact Emerson technical support at <u>www.emerson.com/en-us/support</u>.

Note: These software package versions may change or be removed as needed for updates to this product.

Table 9-1 Open Source Software (OSS) List

Software (by Component)	Company URL	Version	Copyright Notice
EDK	http://www.tianocore.org/	BSD 2.0	Copyright © 2012, Intel Corporation
EDKII	http://www.tianocore.org/	BSD 2.0	Copyright © 2012, Intel Corporation
Crypto Package Using WPA Supplicant	<u>https://w1.fi/wpa_supplican</u> <u>t/</u>	BSD with WPA Supplicant	Copyright © 2003-2016, Jouni Malinen j@w1.fi and contributors
Data Processing Package (Base64 En-/Decoding	<u>https://tls.mbed.</u> org/base64-source-code	Apache 2.0	Copyright © 2006-2015, ARM Limited, All Rights Reserved SPDX-License- Identifier: Apache-2.0
FPGA I2C core	http://opencores.org/projec t_i2c	BSD 2.0	Copyright © 2000 Richard Herveille richard@asics.ws

Acronyms and Abbreviations

- ACPI Advanced Configuration and Power Interface APU Accelerated Processing Unit AMD Advanced Micro Devices BIOS **Basic Input Output System** COM Computer-on-module DDC **Display Data Control Digital Display Interface** DDI DP **Display Port** DRAM Dynamic Random Access Memory DVI **Digital Visual Interface** ECC **Error Correction Code** eDP **Embedded Display Port** EMI Electromagnetic Interference ESD **Electrostatic Discharge** FCH **Fusion Controller Hub** FPGA Field Programmable Gate Array GPI General-purpose Input GPIO General-purpose I/O GPO General-purpose Output HDA **High Definition Audio** I²C **Inter Integrated Circuit** IRQ Interrupt Request LAN Local Area Network LPC Low Pin-Count Interface NC No Connected PCI Peripheral Component Interface PCIE Peripheral Component Interface Express PEG **PCI Express for Graphics Return Material Authorization** RMA RTC **Real Time Clock** SATA Serial ATA SMB System Management Bus SMI System Management Interrupt SPD Serial Presence Detect
- SPI Serial Peripheral Interface
- SSD Solid State Drive
- TDM Time Division Multiplex

- TDP Thermal Design Power
- TPM Trusted Platform Module
- TMDS Transition Minimized Differential Signaling
- UART Universal Asynchronous Receiver Transmitter
- UEFI Universal Extensible Firmware Interface
- USB Universal Serial Bus
- VGA Video Graphics Adapter
- WDT watchdog Timer

Glossary

1	
AC '97	Audio CODEC (Coder-Decoder)
ΑСΡΙ	Software standard to implement power saving modes in PC-AT systems
Basic Module	COM Express 125 x 95 mm (4.9 x 3.7 in) module form factor.
Binary values (base 2	P Represented as digits followed by 'b' (for example 01b).
BIOS before handing contr	Firmware in PC-AT system that is used to initialize system components rol over to the operating system.
BIT	Built-in Test
Carrier Board	An application specific circuit board that accepts a COM Express module.
CE	Conformité Européenne (European conformity)
сстv	Closed Circuit Television
<i>Courier font</i> embedded PC produc	Text in Courier font indicates a command entry or output from a Emerson ct using the built-in character set.
СТДР	Configurable TDP (Thermal Design Power)
CVBS	Composite Video Baseband Signal
cu	Compute Unit
<i>DDC</i> identification of the o	VESA (Video Electronics Standards Association) standard to allow capabilities of a VGA monitor.
DIMM	Dual In-line Memory Module
DP video in a transmissio	VESA-defined digital video interface display port to transport audio and on protocol.
21.4	

DVI Digital Display Working Group (DDWG) standard that defines a standard video interface supporting both digital and analog video signals. The digital signals use TMDS.

EEPR	R OM E	lectrically Erasable Programmable Read-Only Memory
EMI/	/EMC E	lectromagnetic Immunity/Compatibility
ETI	E	vent Time Indicator
EU	European Union	
Exte	nded Module CO	M Express 155 x 110 mm (6.1 x 4.3 in) module form factor.
FCC	Federal Commun	ication Commission (USA)
FR4	A type of fiber-gl	ass laminate commonly used for printed circuit boards.
	Gigabit Gigabit Ethernet	
GT	Giga Transfers I/O	
HDC	P High-bandwidt	h Digital Content Protection
<i>Hexa</i> 0Ch)		ase 16) Represented as digits followed by 'h' (for example:
Неха	adecimal values (b	<i>ase 16)</i> Represented as digits preceded by 'H' (for example: H0C).
Hexa \$0C)		<i>ase 16)</i> Represented as digits preceded by '\$' (for example:
	-	nd data) signaling scheme allowing communication between integrated to read and load register values.
IDE	A parallel Integra	ted Device Electronics interface for hard disk drives (also known as PATA)
Italic or we	c s (Sometimes in eb addresses if un	blue color) emphasizes words in text or documentation, or chapter titles derlined.

Legacy Device Relics from the PC-AT computer that are not in use in contemporary PC systems: primarily the ISA bus, UART-based serial ports, parallel printer ports, PS-2 keyboards and mice.

Definitions vary as to what constitutes a legacy device. Some definitions include IDE as a legacy device.

LPC A low speed pin-count interface used for peripheral circuits such as Super I/O controllers, which typically combine legacy-device support into a single IC.

Least Significant

LVDS Low Voltage Differential Signaling widely used as a physical interface for TFT flat panels. LVDS can be used for many high-speed signaling applications. In this document, it refers only to TFT flat-panel applications.

MS Most Significant

NTSC National Television Standards Committee video broadcast standard used in North America.

PAL Phase Alternating Line video broadcast standard used in many European countries.

POST Power-on Self Test

PCIE Next-generation high-speed Serialized I/O bus

PHY Ethernet controller physical layer device

ROM Read Only Memory, a legacy term often the device referred to as a ROM can actually be written to, in a special mode. Such writable ROMs are sometimes called Flash ROMs. UEFI Firmware is stored in ROM or Flash ROM.

RTC Battery backed circuit in PC-AT systems that keeps system time and date as well as certain system setup parameter.

SATA Serial AT Attachment: serial-interface standard for hard disks.

SBC Single Board Computer

SB-TSI Side Band Temperature Sensor Interface

SCI System Control Interrupt

SPD Serial Presence Detect refers to serial EEPROM on DRAMs that has DRAM

module configuration information.

SPI Serial Peripheral Interface standard for a synchronous serial data bus with Master- Slave devices.

Super I/O An integrated circuit, typically interfaced via the LPC bus that provides legacy PC I/O functions including PS2 keyboard and mouse ports, serial and parallel port (s) and a floppy interface.

SVI2 Serial VID Interface Rev 2

VR Voltage Regulator

TMDS Adigital Transition Minimized Differential signaling protocol between the graphics subsystem and display that is used for the DVI digital signals.

UMI Unified Media interface between APU and FCH

- VGA PC-AT video graphics adapter standard defined by IBM.
- VID Voltage Identification

'#' (hash) suffix to a signal name Indicates an active low signal. The signal is either true when it is at logic zero level (voltage close to 0 V) or the signal initiates actions on a high-to-low transition.

\'(backslash) prefix to a signal name Indicates an active low signal. The signal is either true when it is at logic zero level (voltage close to 0 V) or the signal initiates actions on a high-to-low transition.

GFK-3047C C September 2021

Emerson Automation Solutions 2500 Austin Drive Charlottesville, VA 22911 T +1 800 322 3616 www.Emerson.com

©2021 Emerson. All Rights Reserved.

Emerson reserves the right to modify or improve the designs or specifications of the products mentioned in this manual at any time without notice. Emerson does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Emerson product remains solely with the purchaser.

